

Exterior joinery

Maintenance guidelines

This note gives some basic guidelines on maintaining and redecorating factory finished windows, doors and exterior joinery.

The information relates to water based paints, which dry quickly and with little smell. Applying them requires a different brushing technique (described overleaf) from traditional oil paint.



General Care

Teknos factory applied coatings systems will give many years of life between re painting cycles, and simple steps such as wiping down the joinery finish to remove dirt and insects will help extend the decorative finish. This can be done at the same time as cleaning the glass.

Good household maintenance also helps to extend repainting intervals. At least once a year:

Check hinges and handles and treat with a light oil if necessary

Clean weather seals and ventilators to remove dust or grime

In autumn, clear guttering and down pipes, and repair any leaks

Each spring, inspect the joinery and spot repair any minor areas of coating damage, shakes or open joints.

Repair products

The list below shows the typical maintenance products used to maintain factory finished joinery.

These can be purchased direct from our service centres in Banbury, Livingston and Belfast. Payment is accepted by credit or debit card and orders placed before noon will normally be despatched the same day and delivered by courier within three working days.

Typically 1 litre of primer or topcoat will cover a surface area of 8 - 10 square metres.

Primers and Base Stains	Aqua Primer 2900 base stain
	Anti Stain Aqua 2901 opaque primer
Top Coats	Aquatop 2600 translucent and opaque finish
Ancillaries	Teknoseal 4000 end grain sealer
	Teknoseal 4001 break joint sealer
	Teknofill 5001 fine surface filler

All the recommended Teknos products are water based, with VOC levels significantly below current and proposed legislative levels. Teknos does not use heavy metal additives in any of its products.

First and subsequent redecoration

All areas to be re coated should be lightly abraded with a fine grade abrasive paper, washed down with a mild detergent solution and rinsed with clean water to remove dust, insects and other contaminants, which can form a base for algae and fungi growth.

Using a good quality, long haired, synthetic brush, designed for use with acrylic paints, apply one or two coats of Aquatop 2600 opaque or translucent topcoat in the appropriate shade, colour and gloss level. Allow to dry for four hours between coats.

Problem Areas

If regular maintenance is delayed or some other damage has occurred, additional steps may be necessary to reinstate the finish to its initial condition. The notes below cover the most common problems, and further help is available from our Customer Service teams.

Where minor flaking affects small areas of the topcoat surface but the timber substrate is not exposed:

Abrade the damaged area with a fine grade abrasive paper to remove all unsound coating and feather out to leave a smooth surface.

Clean down and wash the abraded area to remove dust, and allow to thoroughly dry.

Apply a coat of Aquatop 2600 opaque or translucent topcoat in the appropriate shade, colour and gloss level to the damaged area. Allow to dry for four hours and then apply a second coat.

If the damaged area is widespread, lightly abrade the complete frame; repair the damaged area as described above; apply the second coat to the complete frame.

Where moisture has penetrated joints, end grain, mitres or natural movement of the timber has opened shakes, treat as follows:

Abrade the damaged area with a fine grade abrasive paper to remove all unsound coating and feather out to leave a smooth surface.

Clean down and wash the abraded area to remove dust, and allow to thoroughly dry.

Paint with Pride

Prime with Aqua Primer 2900 base coat stain in the original colour for translucent systems or Anti Stain Aqua 2901 for opaque systems.

Seal any open joints with Teknoseal 4001 joint sealer applied by mastic gun. Wipe with a damp cloth or spatula to give a smooth joint and allow to dry to a clear finish.

Seal any exposed end grain with Teknoseal 4000 end grain sealer and allow to thoroughly dry.

Apply a coat of Aquatop 2600 opaque or translucent topcoat in the appropriate shade, colour and gloss level. Allow to dry for four hours and then apply a second coat.

Resin Exudation

Resin occurs naturally in timber, in pockets within the wood or associated with knots. Some timber species are naturally more resinous than others, but the presence of resin is normally not detectable when joinery is manufactured.

Resin exudation often occurs on southern elevations and on darker coloured joinery where the sun's heat liquifies and mobilises the resin drawing it to the surface.

Where resin has exuded through the coating:

Although it may be unsightly, it is better not to remove fresh sticky resin. In practice, this can be very difficult, and its presence indicates that the exudation is still continuing. Remedial work is often best left until the first maintenance period, by which time the resin has normally fully crystallised.

The best remedial treatment is to allow it to weather until it dries and oxidises, forming a white crystalline powder. The dried resin can then be removed with a stiff nylon or natural bristle brush, and any remaining residues washed off with a cloth.

Water based coatings often allow the passage of resin to the surface without damaging the coating. If the finish is not damaged, by over-vigorous scrubbing during crystal removal, re-coating is often unnecessary, but otherwise an overall application of a finish coat restores the general appearance of the timber and maintains its protection.

Applying water based paints

The short drying time and reduced flow of water based paints requires a different technique to achieve a good finish. Following a few simple hints will produce excellent results.

The quality of the brush is very important; a long haired synthetic brush will give the best results. Avoid short haired or worn brushes which may leave lines in the dry film. Thoroughly wet the brush with water before starting, ensuring the base of the bristles (the heel of the brush) is fully wetted.

The viscosity of the paint will affect the ease of application. Whilst the product can be applied directly from the tin, additional thinning with between 5 and 10% of water will improve the flow and levelling properties of the product, particularly in warmer weather.

- For best results follow three simple steps:
- Load the coating generously onto the surface and disperse the paint briskly
- Even out the coating with light diagonal cross strokes, **do not overbrush**, the coating will flow and level naturally
- Finish the application with **light** brush strokes in the direction of the grain

With practice an even coat can be applied quickly. An even coating film is important for durability, but also for appearance, particularly in the case of translucent wood stain.

Apply and finish each section systematically. So on a door or window paint one component at a time e.g. top rail followed by the style and then the bottom rail.

When applying darker opaque colours over previously applied lighter shades use a base coat of the final colour or one coat of Anti Stain aqua 2901 Grey to aid opacity.

Do not attempt to paint when the temperature is below 5 degrees Celsius, or if the relative humidity exceeds 80%: the curing and performance of the coating may be impaired.

If there is any doubt about the substrate or underlying paint film, apply the appropriate Teknos products to a small, inconspicuous area, allow to dry for 24 hours and then inspect for appearance and adhesion to substrate.

Wash out brushes with a mild detergent solution such as washing up liquid then rinse with clean water.

Teknos UK and Ireland

Teknos is one of Europe's leading suppliers of industrial wood coatings. We provide technical support and delivery services throughout the UK and Ireland from 3 service centres, located at Swerford, near Banbury, Livingston and Belfast. For further information, please contact your local service centre.

Teknos (UK) Limited
Unit E1, Heath Farm
Banbury Road
Swerford
Oxfordshire OX7 4BN

Tel. +44 (0) 1608 683494
Fax: +44 (0) 1608 683487

Email: sales@teknos.co.uk
Web: www.teknos.co.uk

Teknos Scotland Limited
Nettlehill Road
Houston Industrial Estate
Livingston
EH54 5DL

Tel. +44 (0) 1506 436222
Fax: +44 (0) 1506 448826

Email: sales.scotland@teknos.co.uk
Web: www.teknos.co.uk

Teknos Ireland Limited
Unit 1
Fortwilliam Industrial Estate
Dargan Crescent
Belfast BT3 9JP

Tel. +44 (0) 2890 960670
Fax: +44 (0) 2890 960674

Email: sales.ni@teknos.co.uk
Web: www.teknos.co.uk



The Wood Window Alliance